OVEN PARTS

For Models: YRBS275PDB7, YRBS275PDQ7, YRBS275PDS7
(Black) (Designer White) (Stainless)

27" BUILT−IN ELECTRIC
SINGLE OVEN
SELF−CLEAN



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: YRBS275PDB7, YRBS275PDQ7, YRBS275PDS7
(Black) (Designer White) (Stainless)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Literature Parts
	LIT8300652	Installation Instructions
	LIT8300772	Use & Care Guide (English)
	LIT8300773	Use & Care Guide (French)
	LIT4451885	Tech Sheet (Oven)
	LIT3191638	Safer Cooking Tips
2		Trim, Side
	4450844	RH Black
	4450845	RH White
	4450847	LH Black
	4450848	LH White
	8281236	Screw
3		Hinge Receiver
	4455605	Left Hand
	4455606	Right Hand
4	4448520	Bumper, Door
7	4455864	Top Chassis
	4449809	Screw
9	4452158	Tube, Vent
	3196176	Screw
10	4452165	Lens, Light
11	4452368	Oven Light Assy
14	4455611	Frame, Front
	4449040	Screw
	4450118	Nut
15	4455381	Gasket, Door
16	4452166	Bulb, Light
19	4451477	Support, Insulation
	4449809	Screw
21		Rail, Side
	4450579	Right Side
	4450580	Left Side
	4448444	Grommet
	4449154	Screw
22	4451896	Latch, Assy
23	4452224	Solenoid
24	4452312	Micro Switch N.C
	4449154	Screw
25	4455641	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4452233	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
28	4451426	Switch, Micro
29	4455636	Sensor
	4449154	Screw
30	4451537	Spring, Latch
37	4451442	Thermostat (TOD) (Temp.) SPST
	4449809	Screw
43	4455529	Base, Chassis
	4449809	Screw
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
51		Trim, Bottom
	4448475	Black Model
	4448476	White Model
	3400832	Screw
53	4449845	Support, Bracket
	4449154	Screw

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449315	Insulation, Wrap
4450364	Insulation, Back

CONTROL PANEL PARTS

For Models: YRBS275PDB7, YRBS275PDQ7, YRBS275PDS7
(Black) (Designer White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Control Panel Assy. W/ Membrane Switch
	8300454	Black Model
	8300453	White Model
	8281179	Screw
2	4451033	Gasket, Control Panel
3	4452901	Microcomputer
	4449745	Screw

OVEN DOOR PARTS

For Models: YRBS275PDB7, YRBS275PDQ7, YRBS275PDS7
(Black) (Designer White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	4455617	Door Liner
2		Hinge, Door
	8300569	R.Side (green)
	8300570	L.Side (green)
	8300571	R.Side (white)
	8300572	L.Side (white)
	4449743	Screw
3	4449253	Glass, Inner
4	4451721	Insulation, Door
5	8300777	Retainer, Glass
	4449809	Screw
7	4449257	Glass, Inner
12		Door Glass, Assy
	4452062	Black Model
	4452063	White Model
	4452478	Black Stainless
13		Door Handle
	4448405	Black Model
	4448406	White Model
14	4450813	Bracket, Handle
	4451040	Screw
	3400832	Screw
15	4452381	Panel, Door (S.Steel Only)
19	4450361	Shield, Heat
	4449809	Screw
20	4451668	Retainer, Glass
	4449809	Screw
21	8300819	Seal, Door
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model
	3400832	Screw
24	4455256	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: YRBS275PDB7, YRBS275PDQ7, YRBS275PDS7
(Black) (Designer White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448715	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: YRBS275PDB7, YRBS275PDQ7, YRBS275PDS7
(Black) (Designer White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	4451759	Exhaust, Vent
2	4455178	Elbow, Vent−Top
3	4455334	Blower
	4455352	Bracket, Blower
4	4451758	Foam, Block
5	4455177	Elbow, Vent−Bottom
11	4449868	Block, Terminal
	3400080	Screw
13	4448548	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Top
	4451597	Right
	4451598	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
16	4450550	Cover, Top Rear
	4449809	Screw
17	4448664	Clamp
	4449809	Screw
18	4450553	Cover, Top Front
	4449809	Screw

MISCELLANEOUS PARTS

For Models: YRBS275PDB7, YRBS275PDQ7, YRBS275PDS7
(Black) (Designer White) (Stainless)

Illus. No.	Part No.	DESCRIPTION

PAINT, TOUCH−UP (1/2oz.)

72017	White
261869	Cord Brown
72032	Black

PAINT, SPRAY

350930	White
261900	Citrine White
830864	Black

ADHESIVE

591014	Adhesive Loctite (1/3 oz.)
482338	Sealer, Silastic (3 oz.)

SPLICING WIRES−−25FT. LENGTH

242828	Wire (12 Ga. 150 c Black)
242820	Wire (14 Ga. 150 c Black)
242821	Wire (14 Ga. 150 c Blue)
242822	Wire (14 Ga. 150 c Brown)
242830	Wire (14 Ga. 200 c Brown)
242823	Wire (14 Ga. 150 c Green)
242824	Wire (14 Ga. 150 c Orange)
242829	Wire (12 Ga. 150 c Red)
242825	Wire (14 Ga. 150 c Red)
242831	Wire (14 Ga. 200 c Red)
242826	Wire (14 Ga. 150 c White)
242827	Wire (14 Ga. 150 c Yellow)
242832	Wire (14 Ga. 200 c Yellow)

WIRING HARNESS PARTS

4455735	Harness, Wire (Main)
4450952	Conduit
4450800	Screw
4448664	Clamp
112432	Nut
4452222	Spacer, Harness
4454835	Tie, Cable
4454842	Tie, Cable
4451761	Support, Wire

Miscellaneous

814381	Pin Hinge Kit
4448950	Screw, Install (4)